
# Eltex yarn break sensors EVG-s



Each sensor has a double modular connector, so they can easily be connected in parallel.

The sensors can be used with a PLC or many other electronic devices like relays, I/O modules, etc.

### Function description

The sensing eyelet is made of aluminium oxide ceramic.

The output reflects the movement of the yarn.

At power-on, sensing is automatically on.

The sensors can be switched off by the touch button or via a terminal in the connector. When switched off, the sensors will automatically resume sensing when yarn movement is detected continuously for seven seconds.

Two dual colour LEDs indicate the state of the sensor.

The LEDs are red when the sensor is off, steady green when on and yarn movement is detected, and slow flashing green when on but no yarn movement is detected.

The LEDs also show the current sensitivity setting.

The sensitivity setting can be changed with the touch button or via a terminal in the connector.

The sensors are protected against wrong polarity on the power supply.




#### Technical specification

Housing in zinc metal		
Power supply	17–30 V DC smoothed ripple.	
	NB! The negative supply must be connected to earth ground to provide proper shielding.	
Current consumption	Max. 15 mA	
Output function	Optocoupler output: The optocoupler is open (off) when the sensor is on and the yarn is moving and also when the sensor is off.	
	The optocoupler is closed (on) when the sensor is on and the yarn is not moving.	
Max. load on output	50 mA	
Reaction time	120 ms	
Sensors connected together	r Not more than 70 sensors should be connected in one chain. For larger applications the Eltex EYE System is recommended.	
For more technical information see instruction leaflet TH-0331.		

Models

ltem No	Eyelet	Notes
16520	Closed Ø 6,5 mm	
16521	Open	
16522	Closed Ø 9 mm	
16523	Quick thread	
16530	Closed Ø 6,5 mm	Air noise filtered
16531	Open	Air noise filtered
16532	Closed Ø 9 mm	Air noise filtered
16533	Quick thread	Air noise filtered





Eltex U.S., Inc. 13031 E. Wade Hampton Blvd., GREER, South Carolina, 29651, USA . Tel: +1 864-879-2131 Fax: +1 864-879-3734 Email: sales@eltexus.com

Box 24, SE-283 21 OSBY, Sweden | Tel: +46 479 536300 | Fax: +46 479 536399 | Email: info@eltex.se | www.eltex.se

## Eltex Manufacturing Ltd.

Railway Road, TEMPLEMORE, Co. Tipperary, Ireland Tel: +353 504-314 33 Fax: +353 504-310 02 Email: info@eltex.ie

#### POLSA-ELTEX, S.L. Zamora, 103 – entlo 3o, ES-08018 BARCELONA, Spain . Tel: +34 93 309 00 17 Fax: +34 93 309 59 45 Email: polsa@infonegocio.com

Eltex China. Beijing S&S Electronics Technology Co., Ltd. B052 F10, SOHO Nexus Center, No.19A, East 3rd ring north Rd., Beijing, China 10020 Tel: +86 10 57351219 Fax: +86 10 65066468 Email: Chuan.Jiang@eltex.cn Web: www.eltex.cn